



e-ISSN: 2319-8753 | p-ISSN: 2320-6710

IJRSET

International Journal of Innovative Research in
SCIENCE | ENGINEERING | TECHNOLOGY

INTERNATIONAL JOURNAL OF INNOVATIVE RESEARCH

IN SCIENCE | ENGINEERING | TECHNOLOGY

Volume 10, Issue 7, July 2021

ISSN INTERNATIONAL
STANDARD
SERIAL
NUMBER
INDIA

Impact Factor: 7.569

A Case Study On “Mix Design and Pumped Concrete”

Abhishek Johnson¹, Harsh Jangid², Nisha Kumari Bairwa³, Javed Ul Islam⁴, Nasir Manzoor⁵,
Charat Lal Meena⁶

UG Students, Department of Civil Engineering, Vivekananda Institute of Technology, Jaipur, India¹⁻³,

Assistant Professor, Department of Civil Engineering, Vivekananda Institute of Technology, Jaipur, India⁴⁻⁶

ABSTRACT: A straightforward strategy for substantial blend plan for pumpable cement dependent on an expected load of the substantial per unit volume is depicted in the paper. The tables and figures introduced are worked out by the creator from a wide scope of Indian materials. The strategy is appropriate for ordinary weight concrete with admixture. The most basic new properties are demonstrated to be extrude ability and build ability, which have shared associations with functionality and open time. These properties are fundamentally affected by the blend extents and the presence of superplasticiser, retarder, gas pedal and polypropylene filaments. An ideal blend is distinguished and approved by the full-scale production of a seat part. Basic ingredients of pumped and normally placed concretes are the same; however, particular attention must be given to the mortar properties, and the amounts and sizes of coarse aggregates. Experiments are described which relate the pump ability, as assessed by a laboratory apparatus, of mixes containing varying coarse to fine aggregate ratios at different slumps.

KEYWORDS: Pumped Concrete, Mix design, Extrusion, Open time, Printing.

I. INTRODUCTION

Concrete is typically positioned into formwork and afterward vibrated to manufacture building parts. Two elective development systems—self-compacting and showered cements—have been created to take out the compaction cycle. The essential rule of self-compacting concrete is that total particles structure a smooth evaluating with a base void substance and a significant volume of Cementitious glue with a superplasticiser, which fill the hole between total particles to make flow ability.

Siphoned concrete may be portrayed as strong that is passed on by weight through either inflexible channel or versatile hose and delivered explicitly into the desired zone. Siphoning may be used for most all strong turn of events, anyway is especially useful where space or access for improvement gear is obliged.

Pumping gear comprises of pumps which are three composes:

- a) Cylinder compose solid pump
- b) Pneumatic write solid pump
- c) and crush weight compose solid pump.

II. LITERATURE REVIEW

AkshaySanepara(2018): researched on the properties of the fine ordinary weight totals (sand) assumed a more noticeable part in the proportioning of pumpable blends than do those of the coarse totals and suggested that pumped cement ought not require any trade off in quality. To be pumpable, an abnormal state of value control for affirmation of consistency must be kept up.

Gibb • T. Thorpe(2012):researched the functionality and the open season of substantial blend. Definitions and test techniques are introduced to assess these new properties which have then been displayed to give solid signs of the exhibition of a scope of blends (with a greatest total size of 2 mm) and the basic new properties of a particularly concrete are extrudability and buildability, which have common connections..

George Ilinoiu(2004): Reasearchedthe suggestions and recommendations for further developing the current substantial blend configuration are unique, as per the variables (human in respect of proficiency of staff/work discipline also, innovative in respect of creation measure) that mediate in the accomplishment of the thought about substantial blend at any rate cost.

III. CONCRETE FOR PUMPING

For the productive siphoning of a strong through a pipeline it is major that the load in the pipeline is sent through the strong through the water in the mix and not through the aggregate, accordingly, this certifications the pipeline is lubed up. In case weight is associated through the all out all things considered, the complete particles will more modest together and against inside the line to shape a blockage; the force needed to move concrete under these conditions is two or three hundred times that needed for a lubed up mix. Expecting, in any case, weight is to be associated through the water, by then it is important that the water isn't blown through the solid constituents of the mix; experience exhibits that water is for the most part easily pushed through particles greater than around 600 microns in distance across and is fundamentally held by particles more diminutive than this. Also, the mix of cement, water and fine all out particles should not be blown through the voids in the coarse absolute. This can be cultivated by ensuring that the complete assessing doesn't have a whole nonappearance of material in two successive sifter sizes – for example, between 10 mm and 2.36 mm. Thus any size of atom should go probably as a channel to expect over the top advancement of the accompanying tinier size of material.



Fig: Concrete Pumping

FUNDAMENTAL CONSIDERATIONS

(a) Cement content-

Concrete without admixtures and of high concrete substance, over around 460 kg/m³ are at risk to demonstrate hard to siphon, in view of high grinding between the substantial and the pipeline. Concrete substance under 270 to 320 kg/m³ relying on the extent of the total may likewise demonstrate hard to siphon due to isolation inside the line.



(b) Workability-

The functionality of siphoned concrete overall have a normal droop of between 50 mm and 100 mm. A substantial of under 50 mm droops are unfeasible for siphoning, and droop over 125 mm ought to be stayed away from. In combinations with high droop, the total will isolate from the mortar and glue and may cause hindering in the siphon lines. The blending water necessities shift from various most extreme sizes and sort of totals. The estimated amount of water for a droop of 50 mm and 100 mm is given in table 4. In high strength concrete because of lower water-concrete proportion and high concrete substantial usefulness is diminished with the given amount of water per cu-m of cement. In such case water decreasing admixtures are valuable. In the expansion of this kind of admixtures at typical measurement levels to get a higher functionality for a given substantial blend, there is no need to make any modification to the blend plan from that created for the substantial of the underlying lower droop. There is for the most part no deficiency of union or abundance draining in any event, when the hydroxycarboxylic corrosive materials are utilized. On the off chance that this class of item is utilized to diminish the water concrete proportion, again no adjustment of blend configuration will be required, albeit little modifications in plastic and solidified thickness will be evident and ought to be utilized in any yield computations.

A deficiency of droop during siphoning is typical and ought to be mulled over while proportioning the substantial blends. A droop deficiency of 25 mm for each 300 meters of course length isn't strange, the sum contingent on encompassing temperature, length of line, pressure used to move the substantial, dampness substance of total at the hour of blending, truck-haulage distance, regardless of whether blend is kept fomented during haulage and so forth. The misfortune is more prominent for hose than for pipe, and is once in a while as high as 20 mm for each 30 meter.

(c) Aggregates-

The greatest size of squashed total is restricted to 33% of the littlest inside breadth of the hose or line dependent on basic math of cubical shape totals. For uncrushed (adjusted) totals, the most extreme size ought to be restricted to 40 percent of the line or hose width.

The state of the coarse total, regardless of whether squashed or uncrushed impacts the blend extents, albeit the two shapes can be siphoned sufficiently. The squashed pieces have a bigger surface region for each unit volume when contrasted with uncrushed pieces and accordingly require moderately more mortar to cover the surface. Coarse total of an extremely terrible particles shape ought to be stayed away from. Troubles with siphon blended have frequently been capable when too enormous an extent of coarse total is utilized trying to accomplish economy by diminishing the measure of concrete such blends are likewise more troublesome and expensive to wrap up.



(d) Pumping-

Before the pumping of concrete is started, the conduit should be primed by pumping a batch of mortar through the line to lubricate it. A rule of thumb is to pump 25 litres of mortar for each 15 meter length of 100 mm diameter hose, using smaller amounts for smaller sizes of hose or pipe. Dump concrete into the siphon stacking chamber, siphon at moderate speed until substantial comes out toward the finish of the release hose, and afterward accelerate to ordinary siphoning speed. Once siphoning has begun, it ought not be intruded (assuming there is any chance of this happening) as substantial standing inactive in the line is responsible to cause a fitting. Critical is to consistently guarantee some substantial in the siphon getting container consistently during activity, which makes essential the cautious dispatching and dispersing of prepared blend truck.




Fig: Relation between free water-cement ratio and concrete compressive strength for different cement strength.

(e) Testing for pumpability-

There is no perceived research facility mechanical assembly or exact piece of hardware accessible to test the pumpability of a blend in the lab. The pumpability of the mix therefore be checked at site under field conditions.

(f) Field practices-

The siphon ought to be as approach the setting region as practicable and the whole encompassing region should have satisfactory bearing solidarity to help the substantial conveyance trucks, in this way guaranteeing a constant stockpile of cement. Lines from the siphon to the putting region ought to be spread out with at least curves. For huge setting regions, substitute lines ought to be introduced for fast association when required. While siphoning lower 15 m or more it is attractive to give an air discharge valve at the center of the top curve to forestall vacuum or air development. While siphoning up it is attractive to have a valve close to the siphon to forestall the opposite progression of cement during the fitting of tidy up gear, or when chipping away at the siphon.



IMPORTANCE OF CONCRETE MIX DESIGN:

A decent substantial blend configuration makes the establishment of a sound framework. *Substantial blend configuration includes a cycle of planning wherein a blend* of fixings makes the necessary strength and sturdiness for the substantial design. Since each fixing in the blend comprises of various properties, it's anything but a simple assignment to make an extraordinary substantial blend. It is basic that all fixings be tried to decide their actual properties and the bearing limit of the venture area. The fixings to be tried: water, fine total (sand), coarse total, concrete, synthetic substances, support, and soil. The upsides of the actual properties got subsequent to testing will be utilized as the reason for all substantial blend plan contemplations. This will guarantee the design will be sound and forestall disappointment of the blend. Note that the elements for the blend may differ starting with one undertaking area then onto the next, so the actual properties should be tried for the prerequisites indicated for every area.




Fig: Concrete Mix Design



TYPES OF CONCRETE MIX:

The two sorts of substantial blend are typical execution concrete and superior cement, and they're portrayed by their compressive strength:

Normal Performance Concrete: An ordinary exhibition substantial blend has a presentation strength going somewhere in the range of 20 and 40 MPa. It is the more utilized blend of the two. Typical execution concrete has great usefulness if the entirety of the blend fixings are in exact extents. When newly blended, the substantial should be plastic or semi-liquid so it very well may be shaped.

High-Performance Concrete: A superior substantial blend has an exhibition strength over 40 MPa. The fundamental reason for utilizing superior cement is to lessen the weight, creep or penetrability issues, and to improve the strength of the design. Like the typical execution substantial blend, this blend should be plastic or semi-liquid when newly blended with the goal that it tends to be formed. Because high-performance concrete has a high cement content, it is often sticky and hard to be handled and placed. However, this does not cause the cement to bleed, an issue that normal performance concrete might run into.

IS Method of Mix Design

Durability Criteria as per IS 456- 2000

Exposure	Plain Concrete			Reinforced Concrete		
	Min. Cement	Max w/c	Min grade	Min. Cement	Max w/c	Min grade
Mild	220 kg/m³	0.60	--	300 kg/m³	0.55	M 20
Moderate	240 kg/m³	0.60	M 15	300 kg/m³	0.50	M 25
Severe	250 kg/m³	0.50	M 20	320 kg/m³	0.45	M 30
V. Severe	260 kg/m³	0.45	M 20	340 kg/m³	0.45	M 35
Extreme	280 kg/m³	0.40	M 25	360 kg/m³	0.40	M 40

Fig: Durability Criteria as per IS456-2000

IV. CONCLUSION

1. Siphoned cement might be utilized for most all substantial development, yet is particularly helpful where space or access for development gear is restricted.
2. Albeit the elements of blends set by siphon are equivalent to those put by different techniques, depending quality control, clustering, blending, hardware and the administrations of staff with information and experience are fundamental for effectively siphoned concrete.



3. The properties of the fine ordinary weight totals (sand) assume a more unmistakable part in the proportioning of pumpable blends than do those of the coarse totals. Sands having a fineness modulus somewhere in the range of 2.4 and 3.0 are for the most part acceptable gave that the rate passing the 300 and 150 micron sifters meet the recently expressed necessities. Zone II sand according to IS: 383-1970 meet these prerequisites, and is reasonable for siphoned concrete.

4. Siphoned cement ought not need any trade off in quality. To be pumpable, a significant degree of value control for affirmation of consistency should be kept up.

5. A straightforward technique for substantial blend configuration will typical weight totals for siphoned concrete is depicted in the paper. The creator had worked out tables and figures from Indian materials by various preliminaries. Consequently the extents worked out with the assistance of these tables and figures will have very close to way to deal with the blend plan issues of the field.

REFERENCES

- [1] Admixtures for Concrete (first revision) BIS: 9103 – 1999, Bureau of Indian Standards, New Delhi.
- [2] Method of test for strength of concrete, BIS: 516-1959, Bureau of Indian Standards, New Delhi.
- [3] Specification for coarse and fine aggregates from natural sources for concrete (second revision) BIS: 383, New Delhi.
- [4] BIS: 456-2000, “Code of practice for plain and reinforced concrete (fourth revision)”, Bureau of Indian Standards, Delhi
- [5] KISHORE KAUSHAL, Concrete mix design containing chemical admixtures, CE and CR May, 1991 pp. 12-20.
- [6] “Pumping Concrete”, Concrete Construction V. 13, No. 11, 1968 pp. 413 – 426.
- [7] Okamura H, Ouchi M (2003) Self-compacting concrete. J AdvConcrTechnol 1:5–15.
- [8] RILEM Technical Committee (2006) Final report of RILEM TC 188-CSC ‘Casting of self-compacting concrete’. MaterStruct 39:937–954.
- [9] http://ijariie.com/AdminUploadPdf/Mix_Design_and_Pumped_Concrete_ijariie8344.pdf
- [10] <https://www.engineeringcivil.com/mix-design-and-pumped-concrete.html>
- [11] <https://www.engineeringcivil.com/theory/research-papers>.
- [12] <https://cyberleninka.org/article/n/1151767>
- [13] https://www.concreteconstruction.net/how-to/materials/making-concrete-pumpable_o



**Impact Factor:
7.569**



INTERNATIONAL JOURNAL OF INNOVATIVE RESEARCH

IN SCIENCE | ENGINEERING | TECHNOLOGY

 9940 572 462  6381 907 438  ijirset@gmail.com



www.ijirset.com

Scan to save the contact details